

These instructions are applicable to Blue Square LED Multi-Color Lights programmed to be compatible with Hayward Controllers. Our LED Pool Lights (H-Series) can be operated from either a wall switch or connected to a Hayward Controller.

When the light has been *off* for at least 20 seconds, and is then turned on, it will start up in Cloud White for 15 seconds-then change to the last Fixed Color or Color Show that was last running. During the 15 seconds of Cloud White, do not operate the wall switch.

When connected to the Hayward Controller, the fixed colors and color-shows can be easily selected using the controller. **When connected to a Wall Switch,** progress to the next program by switching *off*, then back on within -10 seconds. See below table for color program sequence.

If the light has been turned off for between 11 and 14 seconds – and turned back on – it will start up in Program 1 – Voodoo Lounge. This feature is handy to synchronize multiple lights.

PROGRAMMING MODES

Cycles	Mode	Mode Description
1	Voodoo Lounge	Color Show – Fast color wash
2	Deep Blue Sea	Fixed color
3	Royal Blue	Fixed color
4	Afternoon Skies	Fixed color
5	Aqua Green	Fixed color
6	Emerald	Fixed color
7	Cloud White	Fixed color
8	Warm Red	Fixed color
9	Flamingo	Fixed color
10	Vivid Violet	Fixed color
11	Sangria	Fixed color
12	Twilight	Color Show – Slow color wash
13	Tranquility	Color Show – Blue/Cyan/White/Fade
14	Gemstone	Color Show – Blue/Green/Magenta/Fade
15	USA	Color Show – Red/White/Blue/Switch
16	Mardi Gras	Color Show – Fast Random Fade
17	Cool Cabaret	Color Show – Slow Random Fade

Number of times to cycle power (1-17)



For supply connection, use only an isolating low voltage power supply with ungrounded output, evaluated for swimming pool use.